

the hole recess.

11. Drop the small steel disk into the hole, and use the 8-32 screw under the lowest point of the locking tab to support the PMR body and arm.

12. Tap the disk in using a punch, screw, or drift. ONLY APPLY PRESSURE TO THE DISK !! IF YOU HIT THE BODY YOU CAN BEND THE ARM!

13. Once it is all correct, support the magazine latch and tap a few more times. Seat the disk against the center nut or shaft.

14. Verify operation!!!!

This latch has been designed to conform to the law AS WRITTEN in California PC 978.20(a)

**THIS LOCK KIT HAS NOT BEEN
APPROVED BY CAL DOJ.**

Please be familiar with and aware of all current CAL DOJ regulations before installing this button. Please continue to check with CAL DOJ firearms division for any emerging requirements. NEVER

**USE THIS BULLET-BUTTON WITH A MAGAZINE
LARGER THAN 10 ROUNDS CAPACITY IN
CALIFORNIA. FAILURE TO COMPLY WITH THIS
REQUIREMENT IS A FELONY!**

BulletButton.com